

# grotan<sup>®</sup> TK 5

## Preservative for technical products

- Bactericidal effect
- Good immediate effect
- Broad spectrum of efficacy
- Contains no nitrate, nitrosing agents or organically bound chlorine (has no effect on the AOX value)
- Good head space protection
- Neutral pH value
- Contains no organically bound chlorine (has no effect on the AOX value)

### Active substance

<b>EINECS-Name:</b>	<b>CAS-No.:</b>	<b>EC-No.:</b>
(Ethylenedioxy)dimethanol	3586-55-8	222-720-6

### Physico-chemical properties

Colour	colourless - light yellow
Form	Liquid
Odour	aldehyde like
Density (20 °C)	1.248 - 1.260 g/ml
Refractive index (20 °C)	1.456 - 1.569
Initial boiling point	ca. 100 °C
Flash point (ISO 2719)	91 °C
Flow time (DIN 53211 - 20 °C)	< 25 s
Water solubility (20 °C)	in all proportions
Foaming (DIN 53902)	Non foaming (0.15 % in water)
VOC-Content to Directive 2004/42/EC	66 %
pH (10 g/l)	ca. 6 - 8

### Fields of application

The optimum use level should be evaluated by means of a repeated challenge test (e.g. at Schülke Technical and Microbiological dept).  
**Use biocides safely. Always read the label and product information before use.**

	Recommended dosage	
Watermiscable metalworking fluids	1.0 - 1.5 g/kg	(0.10 - 0.15 %)
Technical emulsions	1.0 - 1.5 g/kg	(0.10 - 0.15 %)
Aqueous systems	1.0 - 1.5 g/kg	(0.10 - 0.15 %)
Metalworking fluid concentrates [1.0 - 2.0 g/kg (0.10 - 0.20 %) in the end dilutions]	20 - 40 g/kg	(0.10 - 0.15 %)

### Indications for use

General Information	Grotan <sup>®</sup> TK 5 is suitable for use in water-mixed metalworking fluids, metalworking fluid concentrates and other technical emulsions.
Solubility	Fully soluble in water and in most polar organic solvents.
Recommended use pH range	3 - 12
Maximum use temperature	max. 60 °C
Additional advice	In order to avoid microbial growth and the resultant consumption of preservative from the outset, it is advisable to add Grotan <sup>®</sup> TK 5 to the fresh mix of metalworking fluid. More can be added at weekly to fortnightly intervals depending on the discharge of the metalworking fluid. When adding Grotan <sup>®</sup> TK 5, it should be added at a point with good turbulence in order to ensure good distribution in the system. Before refilling the plant, system cleaning is recommended (e.g. with Grotanol <sup>®</sup> ). In centralised plants with heavy fungal contamination, a combination of Grotan <sup>®</sup> TK 5 with Grotan <sup>®</sup> F 10 or Grotan <sup>®</sup> F 30 is recommended.

### Microbiological efficacy

The efficacy of the product has been tested against the following microorganisms according to DGHM (German Society for Hygiene and Microbiology). Determination of the minimum inhibitory concentration in the serial dilution test produced the following values (MIC in % of the product):

Bacteria (gram-negative)	MIC	Bacteria (gram-positive)	MIC	Yeasts	MIC
<i>Alcaligenes faecalis</i>	< 0.025	<i>Staphylococcus aureus</i>	0.050	<i>Candida albicans</i>	0.400
<i>Escherichia coli</i>	0.050			<i>Rhodotorula mucilaginosa</i>	0.050
<i>Klebsiella pneumoniae</i>	0.050			<b>Moulds</b>	
<i>Proteus mirabilis</i>	0.050			<i>Alternaria alternata</i>	0.050
<i>Pseudomonas aeruginosa</i>	0.050			<i>Aspergillus niger</i>	0.100
<i>Pseudomonas fluorescens</i>	0.050			<i>Aspergillus oryzae</i>	0.100
<i>Pseudomonas putida</i>	0.050			<i>Fusarium oxysporum</i>	0.100
				<i>Penicillium expansum</i>	0.100
				<i>Penicillium funiculosum</i>	< 0.025
				<i>Trichoderma viride</i>	0.050

# grotan<sup>®</sup> TK 5

Compatibility*		
	compatible	to be avoided
concentrate	plastics, sealants, stainless steel, steel, aluminium, zinc, copper	brass
aqueous dilution (0.15 %)	No significant difference to water	Water incompatible materials
Further information	On contact with non-ferrous metal or non-ferrous metal containing alloys, discolourations of the surface wetted with Grotan <sup>®</sup> TK 5 can occur if the coolants do not contain a non-ferrous corrosion inhibitor. From the available test results, it can be concluded that the addition of Grotan <sup>®</sup> TK 5 has virtually no influence on the medium to be preserved. When selecting sealing materials, piping systems, collection baths, etc., the presence of Grotan <sup>®</sup> TK 5 as the preservative in the recommended use-concentration can be disregarded.	

\*Compatibility has to be proved in each case

Labelling	
R-phrases(s)	R22, R36/37/38
S-phrases(s)	S26, S35
Labelling	Xn (Harmful)
For further hazard instructions and safety advice please refer to the actual material safety data sheet.	

Environmental information
At a sufficient degree of dilution, all components of Grotan <sup>®</sup> TK 5 are completely biodegradable. Dilutions of Grotan <sup>®</sup> TK 5 do not normally interfere with the operation of waste water treatment plants. Grotan <sup>®</sup> TK 5 contains no organic chlorine compounds, so that there is no effect on the AOX as a result of Grotan <sup>®</sup> TK 5 in the waste water. The canisters and drums used by Schülke are made of polyethylene (HDPE) and are labelled accordingly. The containers are covered by a return scheme that ensures collection of the used containers free of charge and appropriate reuse all over Europe. The labels are made of PE. Schülke packaging materials contain no PVC and can be recycled. For further information please ask for our detailed environmental report.

Listings and approvals of active ingredients
EINECS / ELINCS (Europe)
TSCA (USA)*
ECL (Korea)
DSL / NDSL (Canada)*
ENCS (Japan)*
AICS (Australia)
PICCS (Philippines)
BfR XIV, XXXVI
Fulfills the requirements of the TRGS 611 (Germany)
* In preserved aqueous products the (ethylenedioxy)dimethanol can be described also as a hydrolyzing product, ethane-1,2-diol and formaldehyde.

Transport & Storage	
Dangerous goods	No
UN-Number	-
Packaging group	-
Package sizes	10 kg, 200 kg, 1200 kg
Shelf life	24 Months
Storage	Protect from frost, heat and direct sunlight. Store at room temperature in the original container.

## Schülke subsidiaries:



**Belgium**  
S.A. Schülke & Mayr  
Belgium N.V.  
1830 Machelen  
Tel. +32-02-479 73 35  
Fax +32-02-479 99 66

**China**  
Schülke & Mayr GmbH  
Shanghai Representative Office  
Shanghai 200041  
Tel. +86-21-62 17 29 95  
Fax +86-21-62 17 29 97

**France**  
S & M France  
75341 Paris Cedex 07  
Tel. +33-1-44 11 00 81  
Fax +33-1-44 11 02 41

**Italy**  
Schülke & Mayr Italia S.r.l.  
20148 Milano  
Tel. +39-02-40 21 820  
Fax +39-02-40 21 829

**The Netherlands**  
Schülke & Mayr Benelux B.V.  
2003 LM-Haarlem  
Tel. +31-23-535 26 34  
Fax +31-23-536 79 70

**Switzerland**  
Schülke & Mayr AG  
8003 Zürich  
Tel. +44-466 55 44  
Fax +44-466 55 33

**The United Kingdom**  
Schülke & Mayr UK Ltd.  
Sheffield S9 1 AT  
Tel. +44-1142-54 35 00  
Fax +44-1142-54 35 01

### Other Distributors:

Argentina · Australia · Austria · Belarus · Benin · Brazil · Bulgaria · Canada · Croatia · Czech Republic · Denmark · Egypt · Estonia · Finland · Ghana · Greece · Hong Kong · Hungary · India · Indonesia · Iran · Israel · Japan · Jordan · Korea · Kuwait · Latvia · Lebanon · Lithuania · Macedonia · Malaysia · New Zealand · Nigeria · Norway · Oman · Philippines · Poland · Portugal · Russia · Saudi Arabia · Singapore · Slovakia · Slovenia · South-Africa · Spain · Sweden · Syria · Taiwan · Thailand · Turkey · Ukraine · United Arab Emirates · USA · Vietnam · Yemen

Our recommendations regarding our products are based on in-depth scientific testing in our Research Department; they are given in good faith, but no liability can be derived from them. It is the responsibility of the final product manufacturer to assure that claims made for the final product are in conformance with all applicable local laws. In other respect our Conditions of Sale and Supply apply.

**Schülke & Mayr GmbH**  
22840 Norderstedt  
Germany  
Tel. +49 40 52100-0  
Fax +49 40 52100-244  
[www.schuelke.com](http://www.schuelke.com)  
sai@schuelke.com